

Fernbedienung
IRC-/ D-/ VD-Phone
P/N 197 1MS1

Level „TV“
 IRC-/ D-Phone

R

Softkey links

Freisprechen
 VD-Phone –
 Softkey links

Abheben
 VD-Phone –
 Abheben

Stern *

Level „PVR“ – IRC-Phone

Level „DVD“ – VD-Phone

Mute

Softkey rechts

„TV“ – Briefsymbol
 VD-Phone – Softkey rechts

Auflegen
 VD-Phone – Auflegen

hoch, runter, links, rechts, ok
 VD-Phone – hoch, runter,
 links, rechts, Schlüssel

Ziffern 0-9

Level „PVR“: Kurzwahl 0-9

Raute #



Alle Signale für IRC- und D-Phone sind in Level „TV“ gespeichert, nur die Kurzwahlsignale für IRC-Phone sind in Level „PVR“!
Level „DVD“ ist nur für VD-Phone verwendet!

Remote Control
IRC-/ D-/ VD-Phone
P/N 197 1MS1

Level „TV“
 IRC-/ D-Phone

Flash

Softkey left

Handsfree
 VD-Phone –
 Softkey right

Answer
 VD-Phone –
 Answer

Star *

Level „PVR“ – IRC-Phone

Level „DVD“ – VD-Phone

Mute

Softkey right

„TV“ – Messages
 VD-Phone – Softkey right

Hang up
 VD-Phone – Hang up

up, down, left, right, ok
 VD-Phone – up, down, left,
 right, Key

Digits 0-9

Level „PVR“: Speed Dial 0-9

Hash #



**All signals are stored in level „TV“, only speed dials are on level „PVR“!
 Level „DVD“ is used for VD-Phone only!**